



First attach the spruce spar into the ribs, then glue a balsa strip on the bottom side and sand it level with the spruce spar. (Not done here yet)







I used pieces of spruce to protect the balsa wood from being damaged by the force of the clamps.